Surface Disinfectant Wipes with a pleasant citrus smell

Cleans, Disinfects³ and Deodorizes non-porous surfaces.



CleanPure is a non-woven, disposable wipe, pre-saturated with a quaternary disinfectant cleaner. It's a strong wipe for tough jobs, made with scrubbing fibers that clean without scratching your surface. **CleanPure** wipes cut grease and grime, clean tough stains, eliminate odors, and leaves a clean, fresh scent. Its antibacterial formula cleans and disinfects³ in one step. It Kills 99.9% of Viruses,* Bacteria and Fungi on hard, non-porous #household surfaces.



Available in 80 and 160 count canisters.
Made in the USA.

FEATURES AND BENEFITS

- CONVENIENT: Multi-purpose sanitizing wipe. One-step cleaning, disinfecting³ and deodorizing on hard, non-porous surfaces.
 Pre-moistened, ready to use wipes that clean with just one wipe.
- **DISINFECTANT**: Disinfects in just 5 minutes²
- BACTERICIDAL/ VIRUCIDAL/PSEUDOMONICAIDAL
- · BACTERICIDAL:
 - ➤ Kills 99.9% of Bacteria in just 15 seconds**
 - Kills Antibiotic Resistant Bacteria: CA-MRSA, MRSA, VISA, VRE and NDM-1
 - Kills 99.9% of Staphylococcus aureus (Staph), Klebsiella pneumonia, Listeria monocytogenes, Escherichia coli (E. coli) 157:H7 in just 15 seconds
 - ➤ Kills Carbapenem Resistant Enterobacteriaceae *****
 - ➤ Kills 99.9% of Campylobacter jejuni in just 1 minute
- · VIRUCIDAL:
 - ➤ Kills Cold¹ & Flu Viruses⁺⁺⁺
 - > Kills influenza A2/Japan the Virus that causes the flu
 - ➤ Kills Pandemic 2009 H1N1 Influenza A Virus
 - ➤ Kills Human Immunodeficiency Virus Type 1 (HIV-1)
 - ➤ Kills Herpes Simplex Virus (HSV-1 and HSV-2)
 - > Kills Hepatitis B Virus and Hepatitis C Virus
 - ➤ Kills Human Coronavirus¹
- FUNGICIDAL:
 - > Kills Trychophyton interdigitale (in 3 minutes)
- **Deodorizer:** Effective against odor-causing bacteria. Leaves a clean, fresh scent.
- Alcohol free. Contains no abrasives or bleach

- ‡‡ When using on food contact surfaces: thoroughly rinse all treated surfaces with potable water.
- ^ "One Step disinfectant" claim is limited to association with non-food contact surface use.
- 2 CleanPure is bactericidal in the presence of organic soil (5% blood serum) against Escherichia coli O157:H7, Salmonella enterica, Pseudomonas aeruginosa, Staphylococcus aureus, Streptococcus pyogenes, Community Associated Methicillin resistant Staphylococcus aureus Genotypes 300 and 400, Methicillin resistant Staphylococcus aureus, Vancomycin resistant Enterococcus faecium, Vancomycin intermediate resistant Staphylococcus aureus and Klebsiella pneumoniae New Dehli Metallo-Beta Lactamase Carbapenem Resistant at 5 minutes contact time.
- 3 When used according to disinfection directions
- 4 When used according to hard surface sanitization directions
- ** Staphylococcus aureus, Klebsiella pneumoniae, Listeria monocytogenes, Escherichia coli 0157:H7
- †††Influenza A Virus, Pandemic 2009 H1N1 Influenza A Virus, Human Coronavirus¹
- †††† Klebsiella pneumonia New Dehli Metallo-Beta Lactamase Carbapenem Resistant
- 1CleanPure is an effective virucide on hard, non-porous surfaces against Human Coronavirus when the treated surface is allowed remain wet for 10 minutes. Allow surfaces to air dry

^{*} VIRUCIDAL/BACTERICIDAL/PSEUDOMONICAIDAL

ACTIVE INGREDIENTS

Alkyl (60% c14, 30% c16, 5% c12, 5% c18) dimethyl benzyl ammonium chlorides	0.14%
Alkyl (68% c12, 32% c14) dimethyl ethylbenzyl ammonium chlorides	0.14%
INERT INGREDIENTS	
TOTAL	100.00%

FOR USE ON

CleanPure is formulated to disinfect hard, non-porous, inanimate environmental surfaces such as floors, walls, metal surfaces, stainless steel surfaces, glazed porcelain, glazed ceramic tile, plastic surfaces, bathrooms, shower stalls, bathtubs, and cabinets.

FOR USE IN

CleanPure is designed as a cleaner and disinfectant for use in medical institutions, hospitals, nursing homes, homes, schools, hotels, restaurants, offices, RV's, trailers, boats, and vehicles. This product is not for use on critical and semi-critical medical device surfaces.

DISINFECTING

To disinfect hard, non-porous surfaces, thoroughly wet the surface to be treated. Treated surface must remain visibly wet for disinfecting. Use enough wipes for treated surface to remain visibly wet for 5 minutes. For visibly soiled surfaces, clean before following disinfecting instructions. Allow surfaces to air dry.

TECHNICAL SPECS

160 Count Canister

- 12 cases of 6 per row
- 10 rows per pallet
- 1836 lbs. per pallet
- 720 tubs per pallet
- 24 pallets per truck
- 17,280 tubs per truck

80 Count Canister

- 24 cases of 6 per row
- 10 rows per pallet
- 1865 lbs. per pallet
- 1440 tubs per pallet
- 24 pallets per truck
- 34,560 tubs per truck

Packaging: Canister

Color: White

Type: Pre-Moistened

Wipe Size: 6" x 6.75" (15cm x 17cm)

Units: 160 sheets/roll

Quantity/Case: 6 rolls/case (80/160 ct)

- Kills 99.9% of Bacteria in Just 15 Seconds!**
- Kills Antibiotic Resistant Bacteria: CA-MRSA, MRSA, VISA, VRE and NDM-1
- Kills Cold¹ & Flu Viruses***
- Kills HIV-1 • Bleach Free
- Alcohol Free

†††Influenza A Virus, Pandemic 2009 H1N1 Influenza A Virus, Human Coronavirus¹

Staphylococcus aureus (Staph), Klebsiella pneumonia Listeria monocytogenes, Escherichia coli (E. coli) 0157:H7

CleanPure is an effective virucide on hard, non-porous surfaces against Human Coronavirus (ATCC VR-740) when the treated surface is allowed to remain wet for 10 minutes. Allow surfaces to air dry.

CleanPure is formulated to disinfect hard, non-porous, inanimate Clean/ure is formulated to disinfect hard, non-portous, nanimate environmental surfaces such as floors, walls, metal surfaces, stainless steel surfaces, glazed porcelain, glazed ceramic tile, plastic surfaces, bathrooms, shower stalls, bathtubs, and cabinets.

Clean/ure cleans disinfects and deodorizes. One step cleaning and disinfecting and deodorizing. This product is not for use on critical and semi-critical medical device surfaces

Active Ingredients:

Alkyl (60% c14, 30% c16, 5% c12, 5% c18) dimethyl benzyl ammonium chlorides . 0.14% Alkyl (68% c12, 32% c14) dimethyl ethylbenzyl ammonium chlorides.. 0.14% INERT INGREDIENTS

MANUFACTURED BY:

Rx SAN, LLC 1877 E. 17th Ave Columbus, OH 43219



EPA REG No.: 1839-190-99437 EPA EST No.: 52823-OH-1



BATCH NUMBER:



Directions for Use:

bilections for Sederal Law to use this product in a manner inconsistent with its labelling. CLEANING: Use one CleanPure wipe to completely remove all dirt and debris from surfaces to be treated.

DISINFECTING: To disinfect hard, non-porous surfaces, thoroughly wet the surface to be treated. Treated surface must remain visibly wet for disinfecting. Use enough wipes for treated surface to remain visibly wet for 5 minutes. For heavily soiled surfaces, clean before following

for 5 minutes. For neavily solied surfaces, clean before following disinfecting instructions. Allow surfaces to air dry.

SANITIZING/DEODORIZING. To sanitize/deodorize hard non-porous surfaces; wipe surface, using enough wipes to allow treated surface to remain wet for 15 seconds for Staphylococcus aureus (Staph) (ATCC 6538), Klebsiella pneumoniae (ATCC 4352), Listeria monocytogenes (ATCC 35152), Esberichiao coli (Ecoli) 0157-IPT (ATCC43955). Let surface dry. For highly solied surfaces, clean excess dirt first. For surfaces that may come in contact with ford, a notable water rises is required. may come in contact with food, a potable water rinse is required CleanPure will not harm surfaces: including acrylic, fiberglass and vinyl. DO NOT USE ON UNPAINTED WOOD. NOT FOR PERSONAL CLEANSING. THIS IS NOT A BABY WIPE! DO NOT FLUSH IN TOILET.

TO OPEN

Remove lid from canister.

Lift flap in center of lid.

Pull up corner of center wipe, twist to a point and thread through dispenser hole in lid. DO NOT PUSH FINGER THROUGH OPENING.

Replace lid. Pull out exposed wipe and snap off.
The next wipe pops up automatically. Dispose of
used wipes in trash receptacle. Snap center flap
down when finished to retain moisture.

• Do not flush.



PRECAUTIONARY STATEMENTS:

PRECAUTIONARY STATEMENTS.

HAZARDS TO HUMANS AND DOMESTIC ANIMALS
CAUTION: Causes moderate eye irritation. Avoid contact with eyes or clothing. Wash thoroughly with soap and water after handling.

thoroughly with soap and water after handling. FIRST AID. Here the product cannister or label with you when calling a poison control center or doctor, or going for treatment. IF IN EYES. Hold eyes open and rinse slowly and gently with water for 15-20 minutes. Remove contact lenses if present, after the first 5 minutes, then continue rinsing. Call a poison control center or doctor for treatment advice. STRABAFE AID INSPORAL:

rinsing. Cell a poison control center or octor for treatment aurove. STORAGE AND DISPOSAL: Do not contaminate water, food or feed by storage or disposal. CANISTER STORAGE/DISPOSAL: Store in an area inaccessible to children. Wipes: Dispose of wipe in trash after use. Do not flush. Canister. Tiphity close lid betwee uses to retain moisture. Namefalleble container. Do not reuse or refill this canister. Offer empty canister for recycling if available or discard in trash